

Morton Rentals, LLC
Guidelines for Inflatables

- Select an area clear of all structures, trees, overhead wires, stumps, rocks, animal droppings, etc.
- If you're on concrete, use a tarp under the inflatable. Do not inflate it directly on the ground.
- After it's inflated, anchor each corner of the inflatable with the stakes provided. Do not use the inflatable without anchoring it.
- Leave the blower continuously running until you need to deflate the unit.
- Inflatables are designed for use by children. Adults are generally too heavy and could be injured or injure others. Parents can accompany young children.
- Children must be supervised by a responsible adult at all times.
- Group children by size; do not allow different sized children on the inflatable at the same time.
- Limit the number of children using the inflatable at the same time.
- Follow all rules listed on the side of the inflatable.
- Remove shoes before using the inflatable.

- No sharp or hard objects (glasses, jewelry, watches, shoes, casts, etc.) are permitted on the inflatable.
- No flips, somersaults or body slamming allowed.
- Jumping is only allowed inside the area enclosed by the safety netting. Do not jump on the loading platform.
- Food, drink, gum, candy, etc. are choking hazards and therefore are not permitted while using the inflatable.
- Do not permit children to play near the fan or behind the rear of the unit where they cannot be readily supervised.
- To prevent the spread of germs, children should wash their hands and faces after using the inflatable.